

NORMAL SERVICE TABLE

10,000+	60,000+	110k+			
MILES	60,000 mi	70,000 mi	80,000 mi	90,000 mi	100,000 mi
Air Filter Element					Replace
Brake Fluid		Replace		Replace	
Cabin Air Filter / Purifier	Replace		Replace		Replace
Engine Oil	Replace	Replace	Replace	Replace	Replace
Keyless Entry Transmitter Battery	Replace		Replace		Replace
Oil Filter, Engine	Replace	Replace	Replace	Replace	Replace
Spark Plug	Replace				
Vehicle	Check	Check	Check	Check	Check